

# JCI 191 Controlled Humidity Test Chamber

*To measure the charge dissipation and capacitance loading capabilities of materials under defined humidity conditions with measurement of temperature and humidity.*

## INTRODUCTION

The ability of materials to dissipate static electricity quickly, as needed if static risks and problems are to be controlled, can depend strongly on ambient humidity.

The reason is that the ease of charge movement depends on the amount of surface moisture that is adsorbed.

Humidity can also affect the 'capacitance loading' experienced by charge on the surface of materials [1, 2]. Studies to compare the capabilities of materials and to judge their suitability for practical applications need to be made under defined and measured conditions of temperature and humidity. The JCI 191 Controlled Humidity Test Chamber provides simple and easy to use facilities in which charge decay and capacitance loading measurements can be made under set condition of humidity using JCI 155 charge decay test instrumentation with various types of sample support [5,6].

The form and facilities of the standard JCI 191 chambers are shown in Figures 1 and 2.

The JCI 191 is available in two versions: the standard version in which the temperature within the chamber can be controlled up to 10°C above ambient, and the JCI 191C version in which the temperature can be controlled from 10°C below ambient to 10°C above.



JCI 191 Controlled Humidity Test Chamber

JCI 191 Controlled Humidity Test Chamber has internal dimensions of 600 x 800mm and 300mm high with a glazed lid that can be lifted up for loading and removal of samples.

The lid is hinged at its rear edge and can open 120° to stay in the open position. Two long sleeve rubber gloves are mounted in the front side so that anything in the chamber can be reached for handling or operation. The size of the chamber is adequate to take a good number of samples and a JCI 155 Charge Decay Test Unit on a JCI 166 Sample Support or a JCI 176 Charge Measuring Sample Support. A JCI 170 or JCI 173 Powder Sample Support may be used for studies on powders. A JCI 150 Faraday Pail with JCI 178 Charge Measurement Unit may be used for charge measurements on powders and small items.

The humidity in the chamber is measured using a semiconductor sensor (Honeywell HIH-3160). This gives a linear response signal from 0 to 100%RH. This has been pre-calibrated at a number of humidity levels against a Rotronic 'Hygropalm' temperature and humidity measuring unit – and the humidity calibration of this is checked against reference salt solutions. A semiconductor sensor is used to measure the temperature within the chamber. The performance of these measurements is checked in situ by comparison to the Rotronic 'Hygropalm' temperature and humidity measuring unit. Observations of humidity and temperature are displayed on separate 3½ digit LCDs on the control box mounted on the right hand side of the chamber.



*Inside of JCI 191 Controlled Humidity Test Chamber*

Humidity is controlled using a circuit that compares the observed humidity to a user set level. If the humidity is above the set level then an electromagnetic airflow valve is opened to provide a supply of lightly pressurised dry air into the chamber until the humidity has fallen appropriately. To achieve levels of humidity above ambient, air from the chamber is recirculated through a 'water bubbler' back into the chamber via a separate input port. The dead band window of humidity control between too dry (amber LED) and too wet (red LED) is about 2%RH. In the middle of the range a green LED shows satisfactory operation.

Dry air may be supplied as a pressure regulated flow from, for example, a cylinder of dry, compressed air or from a special air drier unit, such as the JCI 192 Dry Air Supply Unit. The supply pressure needs to be a few p.s.i. pressure – up to 6 p.s.i. When using the JCI 192, with a fairly modest gas flow capability, it is advantageous to have a small buffer volume (say 10L) in the supply line to give quick response to any ambient air inflow leakage into the chamber that may occur when hands are taken out of the gloves.

Humidity changes and such events are minimised by arranging the gas flow into the chamber to exit via a very flexible buffer volume. This is a light plastic bag in a shielding box. Gas leaks out from this bag via a small hole on the opposite side to the gas entry. If hands are removed from the gloves the bag tends to collapse to back-fill the chamber with air already at chamber controlled humidity conditions.

Temperature in the chamber can be controlled to a set level that is up to 10°C above the surrounding ambient level. This is achieved in a similar way to the control of humidity with heat input controlled by switching mains electrical power to two 50W lamps in a ventilated shielding box in the chamber.

In the JCI 191C a 200W thermoelectric unit is mounted into the left hand side panel. The cooling performance of this is controlled using a proportional control circuit that adjusts the output of the power supply feeding the thermoelectric unit. With the additional thermal insulation on all surfaces of the chamber this enables the temperature in the chamber to be reduced to 10°C below ambient. Insulation on the walls and base of the chamber comprises a 7mm thick sheet of low density polystyrene within outer panels of 6mm PVC. The lid is double glazed with a 6mm thick polycarbonate sheet. To minimise fan noise the power to the internal and external fans is adjusted along with the power to the thermoelectric unit but limited to a lower minimum level. Care should be taken not to obstruct free circulation of air around the outside of the thermoelectric unit.

Air in the chamber is circulated by a continuously running the fan in the heater box and by the small fan in the box mounting the humidity and temperature sensors. These fans aim to give uniform humidity and temperature conditions throughout the chamber. When preparing for measurements with a JCI 155v5 Charge Decay Test Unit it is wise to ensure that air circulation in the chamber can have access to the test aperture of the JCI 155v5 so chamber conditions are also reliably achieved within the JCI 155v5.

To avoid changes in conditions from volume changes when hands are entered and removed from the gloves a flexible plenum buffer chamber is provided at the back of the right hand side panel. This comprises, within the mounting box, a light plastic bag through which air input to the chamber flows out through a small vent hole. Any reduction in pressure within the chamber, when hands are withdrawn from the gloves, collapses the bag to backfill the chamber without drawing back in any outside ambient air.

## CONNECTIONS

The 240V mains power supply input to the control box is via an IEC connector fused at 2A with an anti-surge (slow blow) fuse (20mm long 5mm dia).

Three blanked-off glands are provided in the right hand side panel for user cables into the chamber. These may be used, for example, to provide:

- 18V input from an external switched mode power supply for mains operation and/or battery recharging with a JCI 155v5 Charge Decay Test Unit
- serial data output linkage from a JCI 155v5 or JCI 155v4 Charge Decay Test Unit to an external computer
- analogue signal outputs for remote measurement of charge measurement, for example, when using a JCI 176 in conjunction with a JCI 155v5.

The dry air supply is connected by inserting the dry air supply line into the 6mm push-in pneumatic connector on the upper side of the control box. If the dry air is supplied at a few p.s.i. pressure it is advantageous to have a small buffer volume (say 10l in the supply line. This will give quick response to any ambient air inflow leakage that may occur into the chamber when hands are taken in and out of the gloves several times.

## OPERATION

Temperature and humidity levels are set with the potentiometers on the right of the LCDs when the 'set' buttons are pressed. When the humidity in the chamber is above the set target value the valve to allow inflow of dry air is opened and this is closed when the target level is reached. If the humidity is below the set level then the air pump mounted on the outside of the panel (behind the control unit) is switched on and air is pumped into the chamber via the water bubbler unit. Using the JCI 192 Dry Air Supply Unit and the water bubbler the humidity within the chamber can be controlled from below 15%RH to over 65%RH.

When the temperature in the chamber is below the set target value a heater is switched on to warm the air within the chamber. The 100W heater will give a temperature elevation above ambient up to around 10°C. With the JCI 191C the circuitry in the control unit provides controlled cooling of the air in the chamber when the temperature is above the set level. The 200W thermoelectric cooling unit provides temperature control to 10°C below ambient. The servo control system reduces the cooling power as the target temperature is approached. The power to the fans is also reduced – as will be noted by the reduction in fan noise.

For charge decay and capacitance loading measurements using a JCI 155 Charge Decay Test Unit on a JCI 176 Charge Measuring Sample Support [5] in the chamber it is usually most convenient to place the instruments about in the middle of the chamber. The operator will then easily be able to read instrument displays and select and position samples in the JCI 176. Samples may be placed on one side of the instrumentation and, for example, moved to the other side as they are tested.



*JCI 191C showing power supply and thermoelectric cooler units and overall thermal insulation Controlled Humidity Test Chamber*

The JCI 155v5 is best pre-connected to an external 18V switched mode power supply via the 2.5mm d.c. connector. Mains operation can then be switched on and off externally. Operation of the JCI 155v5 on a mains supply involves a slight heating action within the instrument. This will lower the humidity and raise the temperature slightly. For critical studies it is hence best to pre-charge the batteries of the JCI 155v5, allow a couple of hours for the temperature and humidity to equalise and then make measurements under battery operation.

An earth bonding link should be made between the 'Durable Dot'/Bayonet Pin connector on the sample support and on the body of the JCI 155 and to the earthing point on the chamber. The JCI 155v5 and the JCI 176 will be interconnected using an 8w mini DIN cable supplied with these instruments. The charge measurement port of the JCI 155v5 is that at the left-hand side of the instrument backplate. The JCI 176 will be powered directly from power supplies in the JCI 155v5 and zeroing will be appropriately controlled by the software. It is hence not necessary to have batteries present in the JCI 176 unit or to switch this unit on. Care needs to be taken to ensure these 8w connectors are pushed fully home into the sockets and it will be best to connect the smaller section 8w plug to the JCI 155v5.

When JCI 155v4 instruments are used in the chamber the 8w mini DIN to 9w D type connector serial communications lead is plugged into the 8w min DIN socket in the back plate of the JCI 155. If a JCI 176 is used the 8w min DIN plug for external charge measurements may be plugged into either of the two 8w min DIN sockets in the back plate of the JCI 176 unit. In this case the JCI 176 will need to be fitted with batteries and switched on (or powered from an external supply) for taking measurements. Operating the zeroing button of the JCI 176 through the gloves on the chamber will not be easy. It will be better to arrange for a zeroing push button to be connected via the 8w lead for external operation.

Before starting test work it is wise to check that the operator can easily enter hands into the gloves and can handle and control any item within the chamber volume. It may be advantageous to put a little talc powder on the hands to make it easy to put them into and take them out from the gloves. For operation at low or high temperatures it may be helpful to wear light cotton or nylon gloves within the chamber gloves.

When several samples are put into the chamber it will be wise a) to keep these separated to minimise chance of transfer of surface treatments between samples, and b) to make it easy for samples to acclimatise to local environmental conditions. It may prove helpful to have small wire racks within the chamber to store samples with segregation. At least 24 hours should be allowed for acclimatisation of samples – possibly longer for getting to low humidity levels.

When loading samples between the sample support plates of the JCI 176 (or between the JCI 155 and a JCI 166 Sample Support) it is important to check that the upper surface of the sample is flat and smooth and that there is no chance that loose fibres or pieces of material will get into the test aperture of the JCI 155. Many samples are easily charged by rubbing. It is hence important to minimise sliding and rubbing actions in positioning samples between the plates of the JCI 176. When testing samples that may

+

include high conductivity threads it is wise to avoid these touching the earthed sides of the JCI 176 as this could affect charge measurement performance.

### **JCI 192 DRY AIR SUPPLY UNIT**

The JCI 192 Dry Air Supply Unit provides a low pressure flow of very low humidity air via a push-in connector for 6mm airline plastic tube. This tube (typically 3m long) can be connected directly to the input push-in connector on the control box of the JCI 191. The supply pressure is set to operate over an output pressure range between about 0.05 and 9 p.s.i. The air normally has a dewpoint of  $-40^{\circ}\text{C}$  or less.

The front panel includes a mains ‘On/Off’ switch, a 1A fuse, a counter to show the accumulated hours of compressor operation, an LED display of internal air pressure or dewpoint – push-button selected. The unit is set at manufacture for either 240V or 115V operation. Indicator LEDs on the front panel show status for pressure and dewpoint. When the Controlled Humidity Chamber is demanding air from the unit the internal air pressure may fall below the low set point. This may well cause the ‘Low pressure’ indicator light show. This is not a problem situation so long as pressure starts to build as soon as the flow into the JCI 191 is switched off by its control unit. It may be necessary to close the bleed valve a bit if the pressure rises but then falls away rather quickly when the compressor switches off.

When the unit is first switched on after it has been idle for a long time initial dewpoint may be up at  $+2^{\circ}\text{C}$ . The dewpoint can be expected to fall to  $-40^{\circ}\text{C}$  within an hour after switch-on. If no dry air was used from the unit the dewpoint would gradually rise. If this continued the supply of air would be switched off when the dewpoint of the air supply had risen to  $-27^{\circ}\text{C}$ . There is a bleed valve on the front panel and this is set to normally give sufficient airflow to keep the humidity well below  $-27^{\circ}\text{C}$ . However, if the humidity



rises above this level when the unit is not supplying dry air then the needle valve in the front panel may be opened a bit (anticlockwise). The dewpoint level should decrease, and when this is below  $-27^{\circ}\text{C}$  dry air will be able to be supplied.

It needs to be noted that the lowest level of humidity achievable depends upon the ambient temperature and humidity. Levels down to 20%RH should be readily achieved. Levels down to about 10% should be achievable but it may be necessary to ensure the ambient temperature and humidity are at moderate levels.

## **SPECIFICATION FEATURES**

<b>Internal Chamber size:</b>	600mm (w) x 800mm (l) x 300mm (h)
<b>Measurements:</b>	humidity and temperature values are displayed on a 3½ digit LCD
<b>Humidity control:</b>	within about +½ % from below 15%RH to over 65%RH
<b>Temperature control:</b>	from ambient to about 10°C above - with JCI 191C from 10°C below ambient to 10°C above
<b>RH/T Display:</b>	Humidity to 0.1% Temperature to 0.1°C.
<b>Controls:</b>	Push buttons to enable target humidity and temperature levels to be set with potentiometer
<b>Dry air supply:</b>	Standard 6mm push-in plastic tube connector. Dry air supply 0.1 bar about 1litre min-1 (for example from JCI 192 Dry Air Supply Unit)
<b>Power supply:</b>	Mains power is connected via an IEC connector on the Control Box. Operation from 240V 5VA supplies. Fused at IEC socket 3A with a 'SoBlo' fuse. External supply should be fused 3A.
<b>Signal connections:</b>	3 gland seals provide for linking signals from instruments within the chamber to external control and display facilities

### **REFERENCES:**

[1] J. N. Chubb "New approaches for testing materials" J. Electrostatics 54 March 2002 p233.(Proceedings ESA Annual meeting, Brock Univesity, Niagara Falls, June 18-21, 2000).(This paper is available on the JCI Website at <http://www.jci.co.uk/Papers/ESA-MaterialTesting.pdf>)[2] J. N. Chubb "Measurement of tribo and corona charging features of materials for assessment of risks from static electricity" IEEE-IAS Meeting, Phoenix, Arizona, Oct 1999. IEEE Trans Ind Appl 36(6) Nov/Dec 2000 p1515-1522 (This paper and copies of the overhead transparencies used are available on the JCI Website at <http://www.jci.co.uk>)[3] BS 7506: Part 2: 1996 "Methods for measurements in electrostatics" British Standard Institution[4] IEC 61340-5-1: 1998 "Electrostatics – Part 5-1: Protection of electronic devices from electrostatic phenomena – General requirements" (Technical Report) International Electrotechnical Commission[5] "Method for testing the electrostatic suitability of materials" document proposed to British Standard committee GEL101. (JCI Website at <http://www.jci.co.uk/List.html>)[6] J N Chubb "A Standard proposed for assessing the electrostatic suitability of materials" J. Electrostatics 65 2007 p607-610



**JCI Chilworth** manufactures a wide range of high quality, state of the art electrostatic instrumentation. We also carry out servicing and repairs for JCI instruments, and where appropriate calibration traceable to national and international standards. **JCI Chilworth** is part of **Chilworth Global**.

**Chilworth Global** brings together leading expert consultants in the fields of electrostatics and process safety, and GLP compliant laboratories, to provide a single point of contact for all electrostatic and process safety needs. Our laboratories provide material properties data for electrostatic problems and hazards, fire and explosion hazards (including liquids, vapours, gases and powders), chemical reaction hazards and regulatory testing. Our consultant engineers are all experienced in process safety, with individual expertise that includes electrostatics, chemical reaction hazards, and other particular aspects.

## Contact Information ►

For further information on JCI Chilworth products and services visit:

**[www.jci.co.uk](http://www.jci.co.uk)**

**email:** [sales@jci.co.uk](mailto:sales@jci.co.uk)

For Further information on Chilworth Global process safety services visit:

**[www.chilworth.co.uk](http://www.chilworth.co.uk)**

**email:** [info@chilworth.co.uk](mailto:info@chilworth.co.uk)

Chilworth Technology Ltd  
Beta House, Southampton Science Park  
Southampton, SO16 7NS, UK

**Tel :** +44 (0)23 8076 0722

**Fax:** +44 (0)23 8076 7866